


How to change the satellite on a Satmatic HD Fransat receiver?

Option 1



1. When the antenna is in search mode, press the *green* button on your remote control



2. Select the desired satellite..
3. The antenna will align itself with the selected satellite.

How to change the satellite on a Satmatic HD Fransat receiver?

Option 2



- While a channel is displayed, press the 'List' button on your remote control.



2. Select the desired satellite.
3. The antenna will align itself with the selected satellite.